

WARNING

BEWARE of HIGH WINDS

Slidetrack blinds have been successfully used in thousands of locations in Australia. Where blinds are more than 7.5 square metres in area we recommend they are always retracted in storm conditions.

Performance of the blinds in wind depends on how exposed they are and the size of the blinds. Your retailer can provide guidance based on your specific conditions.

When lowering motorised blinds in windy conditions it is essential that the operator observes the blind descending and provides manual assistance if it hesitates because of the side friction increasing due to the wind load.

WARRANTY

Materials used in Slidetrack Blinds are covered by a limited warranty when installed correctly and used under normal operating conditions. For detailed inclusions and relevant time periods, or for more information on operation and maintenance, please contact your retailer or visit www.ozroll.com.au

Slidetrack[®]
OUTDOOR BLINDS by **OZROLL**

OPERATION & CARE GUIDE

OZROLL
We Simply Do It Better

MAINTENANCE

Your blinds should be cleaned whenever visible dust build-up occurs, and a soft-bristle brush dipped in a bucket of clean water or connected to a hose works well. A soft cloth or chamois can be used to dry off PVC blinds.

It is important that the side track grooves are lubricated using silicone from a spray can with a nozzle at least four times a year and particularly following rain, to restore lubricity to the side spline. Only silicone is recommended.

SETTLING PERIOD

We recommend that during the first week after installation the blinds are left down as much as possible to permit the fabric to conform to shape. When you start using the blinds, you may notice that not all of the bottom bars sit level at the top. This effect will normally reduce over time.

Slidetrack
OUTDOOR BLINDS by **EZYROLL**

BEFORE SETTLING

AFTER SETTLING

**E-TRANS
1 CHANNEL
OR 9 CHANNEL**

OPERATION

MOTORISED

Motorised blinds will be operating by remote or wall switch, depending on the system chosen. Speak with your retailer about your motor type for specific instruction. It is important to watch your blinds during operation – any obstacles or strong winds can prevent the blind from detracting, which will cause the skin to bunch up on the axle and potentially damage the system.

MANUAL with SPRING ASSIST

The Ezylift Handle operates locking pins, which can be set at multiple heights, however the blind can be left at any height without being locked. Hold the bottom bar near the centre to raise and lower the blinds slowly and smoothly (raising the blind too rapidly can result in a jam if the fabric is not rewinding smoothly).



EZYROLL
We Simply Do It Better